

# THE BRICKERY®

## Venetian Crystal Glass Bricks: Important Note – Weldcrete

---

When bonding Venetian crystal glass bricks, it's crucial to use brick mortar with a recommended 10mm joint. Note that glass bricks, being non-absorbent, necessitate the addition of a bonding agent to the mortar for sufficient bond strength. To enhance strength, we advise mixing an M4 equivalent mortar with a product such as Weldcrete.

Weldcrete, distributed by Cementaid in Australia, is the recommended product for this purpose. Regrettably, we're currently unaware of any New Zealand-based distributors for Weldcrete. For more information on Weldcrete and its availability, please visit Cementaid's website: [cementaid.com](http://cementaid.com)

For detailed guidance on installation, refer to Brickworks' instructional video on YouTube: [Installation Video / Venetian Glass Bricks - YouTube](#)